

Getting Started

AVC3003

1



Connecting the Camera to LAN

Connect the camera to your network with the provided Ethernet cable.

2



Connecting the AC Power Adapter

When you connect the power adapter, the camera is powered on automatically. You can verify the power status from the Power LED on the back panel of the camera. Once connected, the Link LED starts flashing and the camera is on standby and ready for use.

3



Accessing to the Camera

Go to the LiveLine web site to download software.

Event Recording (Optional):

LiveLine cameras can be set to record.

Connecting Your Camera To A Wireless Network:

Make sure the camera is on and plugged into a router, and log into your camera to set up.

Monitoring:

Go to www.liveline.net to download software.

Package Contents

- 1 IP Camera
- 1 Power Adapter
- 1 External Antenna
- 1 Wall Mount Kit
- 1 GPIO Connector
- 1 Ethernet Cable
- 1 Quick Start Guide

AVC3003

